

# I-PLUG TH User Manual

**Company:** Switrac SA

**Brand Name:** I-PLUG TH

**Product Description:** Temperature and humidity Data Logger, multi or single use

## Features and Advantages:

- Dimensions: 7.5 cm x 4 cm x 0.5 cm
- Temperature measurement range: -35 to +65 Degrees Celsius
- Temperature resolution: 0.01 °C
- Data storage capacity: 30 000 Measurements (15 000 for temperature, 15 000 for humidity)
- Log cycle: 1 days to 90 days
- Program and read the device using free MANAGER software
- Track and trace of settings, graph and readings in web portal.

## Standard available durations:

	Total Time (Days)	Log Cycle (Minutes)
1	10	1
2	20	2
3	62	6
4	90	9
5	104	10
6	156	15
7	312	30

## Appearance of I-PLUG TH :



## How does it work?

### How to START it?

When you are ready to use **I-PLUG TH Logger**, press and hold the START button. The 4 LEDs will light sequentially, release only when the GREEN LED only is lighted. If the device failed to start the 4 LEDs blink together, in this case repeat the operation.

Once started, the GREEN LED will blink every 2 seconds, for the first 30 minutes.

*NOTE: on older devices the GREEN LED remained lighted during the first 2 minutes, without blinking.*

After this phase, if you want to read the device status press briefly any of the two buttons (see the section Understanding the LEDs indicators).

### Start Delay

As a factory setting, I-PLUG TH will start recording 30 min after pressing the START button.

### How to STOP it?

I-PLUG TH is programmed with a typical trip duration, and will keep recording until the end of this trip duration

There are two different ways to STOP the device before the end of the trip duration:

- Press the **STOP** button during 6 seconds till the 4 LED's flash – release only when the RED LED is active and fixed.
- **Connect** the device on the USB port of the computer

Once stopped, pressing any button will briefly activate The RED LED as an indication that the device has finished recording.

## Configuring I-PLUG TH

I-PLUG TH data logger comes already configured to standard formats according to your purchase.

The standard trip duration is **90 days**.

Nevertheless if you wish to change the configuration like

- Changing the recording time
- Temperature scale (C°/F°)
- Adding alarms (**for temperature only**)
- Changing start delay
- Entering text in the device memory







You just need to plug it in a computer before being activated and use the **iPlug Manager** software. **Contact your SWITRACE distributor to receive this free software.**

## Understanding the LEDs indicators

The LEDS will give you valuable information of the conditions of your shipment as indicated in below table.

If you press START or STOP button briefly, while I-PLUG is running, LEDs will blink.

Here are the meanings:

Appearance of I-PLUG pdf	Meaning
	<b>4 blinking LEDs</b> Ready state / Device has not been started. NOTE: When the device is in a Ready state, <u>only the start button is active.</u>
	In a RUNNING state, when a button is pressed: <b>Blinking Green</b> This confirms that the device is already started. NOTE: <u>there is a fixed green LED during the first 2 minutes of recording.</u>
	<b>Fixed Red</b> Device is in a STOP state.
	In a STOP state, when a button is pressed: <b>Blinking Blue</b> Low alarm has been triggered. <b>Fixed Blue</b> Ultra-low alarm has been triggered.
	In a STOP state, when a button is pressed: <b>Blinking Orange</b> High alarm has been triggered <b>Fixed Orange</b> Ultra-high alarm has been triggered.
	SAMPLING state. <b>Orange LED</b> automatically lights for 2 seconds every time the device performed a temperature record.


## Connecting to the computer

I-PLUG TH will be detected by the computer as a USB disk drive and will be recognized without any specific driver. There are, however, two possible situations.

- **Device is not started:** If you need to modify any of the parameters before starting the I-PLUG TH, plug the device in a USB port then **press the START button**, for the computer to detect it.
- **Device is working or stopped:** As soon as the I-PLUG TH is connected to the PC via the USB port the computer will automatically detect the device.


## Using I-PLUG Manager for immediate readings

1. Connect the device to your computer
2. open SWITRACE MANAGER for immediate readings
3. select “Read Temperatures” for immediate readings



Pic.1

Temperature and humidity information will be displayed on the same page, Humidity graph in BLUE, and temperature graph in RED



Pic.2


## Track and trace of I-PLUG TH:

Once the device has been stopped, and plugged into the PC, with **iPlug Manager** you could send the data recorded to the web, and allow yourself to export data in excel files, zoom on the graph and many other features.


Just press the **UPLOAD TEMPERATURES** button (see in Pic.1) and your preferred browser should open, bringing you directly to the web-application.

### Online view requires internet connection

If you want to access your saved data remotely, go to the [www.switrace.com](http://www.switrace.com) then insert the serial number of the logger in the SEARCH field, and you will have access to the web-application again (Pic.4)



Pic.3



Pic.4

## Modify settings of I-PLUG TH:

**iPlug Manager** allows you to modify all the pre-programmed setting and choose your own.

Just modify all the parameters you need, then press the **Save settings** button (Pic.1). You can change hereafter parameters (Pic.1)

- trip duration
- sample frequency size
- Start delay
- Temperature alarms

## Restarting I-PLUG TH :

If the device is in a **STOP** state, **iPlug Manager** allows you to reset I-PLUG TH for as many time as you want. By default, it will read the last configuration used.

You can modify the parameters again (if needed), then just check the **Reset device** flag (Pic.1), then press the **Save settings** button (Pic.1) : green LED will flash 1 time to indicate that new settings have been recorded.

The device will be in a **READY** state again.

Battery is NOT changeable by user, please bring the device back to your distributor once the battery runs out of power for recycling.

**IMPORTANT:** When you reset I-PLUG TH, all the previous recording will be erased. If you need to store them, be sure, before resetting, to upload them in the web-application (press **Read Temperatures**).

## For further questions

**Please contact:**

SWITRACE SA

Via F. Catenazzi 5

6850 Mendrisio

Switzerland

Phone : +41 91 646 18 74

E-mail : [info@switrace.com](mailto:info@switrace.com)